

There is two way to setup the preset and Tour as below

1. with Hikvision NVR, you should enter to the "PTZ control" and "Configure" the preset directly



then setup the preset it here.



Call the preset here.

Guard tour 1, please call the preset+98(preset 1 to 16)

Guard tour 2, please call the preset+97(preset 17 to 32)

Guard tour 3, please call the preset+96(preset 33 to 48)



2. Or you should call preset 95 enter to the OSD of the camera to setup/call the Tour and preset.





